

Mitnehmer / Adapter

Drive wheels and adapterrings

Entraîneurs et adaptateurs

Nur für
Serien

ABS 50

Only for
series

S-ABS 50

EL1 / 4 50

Seulement
pour séries

ABS 50 NHK

- passend zu allen gängigen Wellen
(für andere Wellen auf Anfrage)




- for most of usual tubes
(for other tubes on demand)

- Ils s'adaptent sur tous les axes habituels
(pour d'autres axes sur demande)

Bei EL1 / 4 50- und S-ABS-Motoren, nur Mitnehmer ohne ABS verwenden.

With EL1 / 4 50- and S-ABS-motors, only use drive wheels without ABS

Avec des moteurs EL1 / 4 50- et S-ABS, utiliser seulement des entraîneurs sans ABS

Welle / tube / axe	Artikel-Nr. / type no. / référence			Welle / tube / axe	Artikel-Nr. / type no. / référence		
	Mitnehmer drive wheel / entraîneur mit ABS ohne with without avec sans	Adapter adapter adaptateur			Mitnehmer drive wheel / entraîneur mit ABS ohne with without avec sans	Adapter adapter adaptateur	
	55200K	55201K			55218K 55236K	55219K 55237K	57218 57208 + 57270
SW 50 (52) Selve	55234K	55235K	57234		55230K exz. 55218K	55231K exz. 55219K	57230 exz. 57218
SW 60 Selve, Döhner	55202K	55203K	57202				
Müller, Eckermann, Hoos, Weisbender	55220K	55221K	57220				
SW 70 Selve	55222K	55223K	57222				
	55204K 55232K	55205K 55233K	57204 57232				
	55206K 55224K	55207K 55225K	57206 57224				
	55220K 55222K	55221K 55223K	57220 57222				